


Vacuum Science and Technology for Accelerator Vacuum Systems

*Yulin Li and Xianghong Liu
Cornell University, Ithaca, NY*



Cornell Laboratory
for Accelerator-based Sciences
and Education (CLASSE)






Table of Contents

- Vacuum Fundamentals
- Sources of Gases
- Vacuum Instrumentation
- **Vacuum Pumps**
- Vacuum Components/Hardware
- Vacuum Systems Engineering
- Accelerator Vacuum Considerations, etc.

SESSION 4: VACUUM PUMPS

- Category of Vacuum Pumps
- Displacement Pumps (Sec. 4.1)
- Capture Pumps (Sec. 4.2-4.4)
- Accelerator Pumping Considerations

Two Major Categories of Vacuum Pumps



Based on how the gases are removed from gas phase



Displacement Pumps

- Pumping by displacing gas to outside of the vacuum envelope, via **volume exchange**, or **momentum transfer** to compress and to convey gaseous molecules to the exhaust
- Primary pumps can start from atm. Pressure.
- No capacity limit
- Moving parts may fail in continuous operations. Potential contamination.

Capture Pumps

- Pumping by storing, or capturing gas molecules through **chemi-** or/and **physi-**sorption onto the pumping elements
- No moving parts, clean
- Can't (effectively) operate at high pressure
- Limited pumping capacity





□ Pumping Speed

- Pumping speed of a pump is the volumetric rate at which gas is transported across the pump inlet port.
- It has a dimension of volume per unit time. Commonly used are: m^3/s , CFM, m^3/h , L/s
- Pumping speed is usually pressure dependent, and gas dependent.

□ Working Pressure Range and Ultimate Pressure

- Every pump has a finite range of pressure in which it performs effectively in removing gases.
- Ultimate pressure is the lowest pressure a pump can achieve with inlet blanked off.

□ Pumping Capacity

- Most capture pumps have finite pumping capacity, which measures a mount of gases it can capture either (1) before a regeneration is needed, or (2) a pump has to be replaced



Measuring Pumping Speed


Pumping Speed Measurement



- ❖ *In most applications, the pumping speed information supplied by the pump manufacturers is sufficient.*
- ❖ *However, there are needs for measuring pumping speed of a pump for reasons such as:*
 - *To verify pumping performance, after a pump rebuild or recondition.*
 - *To measure pumping speed for a specific gas*
 - *To measure pumping speed at specific conditions (different operation voltages, temperature, magnetic environment, etc.)*
- ❖ *Pumping speed is defined as: $S = Q/P_{inlet}$. So both the throughput (Q) and pump inlet pressure (P_{inlet}) need to independently measured in pumping speed measurements.*
- ❖ *There are two AVS recommended methods of pumping speed measurement: the flow-meter method and the conductance (orifice) method.*



- Gas is introduced into the test dome with a known rate, Q
- Q is controlled either with a flow-meter (at high loads), or using a calibrated leak.
- $S = Q / (P - P_0)$, P_0 is the base pressure.
- This is mostly used for primary pumps




From: M. H. Hablanian, J. Vac. Sci. Technol. **A5**, 1987, p.2552

Pumping Speed Measurement – Orifice Dome




- An orifice with defined geometry defines the flow rate.
- $Q = C_{orifice} \times (\Delta P_1 - \Delta P_2)$
- $S = Q / \Delta P_2$
- This is mostly used for HV and UHV pumps. No need for calibrated flow rate control.



From: M. H. Hablanian, J. Vac. Sci. Technol. A5, 1987, p.2552



Flow Control – Flow meters



- ❑ Flow rates: 5 sccm ~ 10 slm (N₂ equivalent)
- ❑ Precision: 0.1% ~ 1% F.S.






- ❑ *Crimped capillary leaks are widely used*
- ❑ *Flow (leak) rates: 10^{-9} to 10^{-4} torr·l/sec for most stable gases (single and mixtures)*
- ❑ *Very reproducible gas sources (with periodic calibrations)*
- ❑ *NIST-traceable calibrations*



Variable leak valve specifications

Minimum leak rate	1×10^{-9} Torr-litres/sec. in normal operation; 1×10^{-10} Torr-litres/sec. with condensable vapours eliminated from leak gas
Rate of change of leak	The valve provides an increasing rate of change as the size of the leak increases giving precise control in proportion to the size of the leak
Vacuum range	From atmospheric pressure to below 10^{-11} Torr
Temperature range	Up to 450 C in either open or closed position
Inlet gas pressure	500 psi maximum
Gasket life	For unbaked systems, approximately 300 closures; For baked systems, 20 to 30 closures Gasket assemblies are replaceable
Material	300 series stainless steel; sapphire; OFHC copper and copper alloy
Weight	1.8 Kg (4 lbs)



Displacement Pumps

Based on working pressure ranges

Primary Pumps

HV-UHV Pumps

Oil-sealed or "Wet" Pumps

- *Rotary vane pumps*
- *Piston pumps*
- *Roots pumps*

Diffusion Pumps

Turbo-molecular pumps

Dry Pumps

- *Diaphragm pumps*
- *Scroll pumps*
- *Screw pumps*


Primary Pumps



Type	Advantages	Disadvantages
Rotary Vane	Low Ultimate Pressure Low Cost Reliable	Source of Backstreaming Oil & Hazardous Waste
Rotary Piston	High Pumping Speed Low Cost	Noisy Source of Vibration
Scroll	Clean Low "clean" Ultimate Pressure	Permeable to light gases Clean applications only
Diaphragm	Quiet Easy to work on	Low Pumping Speed High Ultimate Pressure Requires frequent servicing
Roots Blower	No (Low) Backstreaming Low Ultimate Pressure	Expensive Requires frequent servicing Requires purge gas
Screw Pump	Handle high displacement rate Work with condensable gases/vapors Quiet operation	Expensive Heavy





Rotary Vane Mechanical Pumps




Rotary Vane Mechanical Pumps



- ❑ *Spring loaded on eccentric rotors compress gas from inlet to exhaust*
- ❑ *Single-stage and two-stage versions are available*
- ❑ *Gas displacement speed up to 100 m³/h*
- ❑ *Ultimate pressure for two-stage pumps 10^{-3} torr. Limited by leak through oil-seals and 'dead' volume*
- ❑ *Rugged, long-term continuous operations.*
- ❑ *Suitable for LV systems, and backing for HV pumps.*
- ❑ *Main drawback: oil back-stream*





Diaphragm Pumps




Diaphragm Pumps




- ❑ Dry primary pumps. Usually available in multiple stages (up to 8 stages)
- ❑ Quiet operations
- ❑ Ultimate pressure ~ 1 torr
- ❑ Require more frequent maintenances





Scroll Pumps



Scroll Pumps




- The scroll pump is a relative simple dry compressor, with two spiral surfaces, one fixed, on orbiting. Teflon tip seals are commonly used, and easy to replace.
- Pump sizes: 15-40 m³/h; ultimate pressure ~10⁻² torr.
- Moving scroll may create dust at exhaust. Moisture may shorten scroll lifetime



Screw Pumps – Archimedes' screw



The Archimedes' screw, also called the Archimedean screw or screw-pump, is a machine historically used for transferring water from a low-lying body of water into irrigation ditches.





Invented 3rd BC



Still in use today




Screw Pumps – Moving/Compress Gases




Screw Pumps



- ❑ *Screw pumps are dry compressor, consisting of a pair of counter-rotating shafts.*
- ❑ *Screws pumps can have very high pumping speed (up to 2500 m³/h), and lower ultimate pressure (5x10⁻³ torr)*
- ❑ *Screw pumps can handle corrosive, abrasive and condensable gases/vapors.*
- ❑ *Relatively high cost*



BUSCH Cobra description




- 1.Inlet - 2.Exhaust - 3.Water Jacket - 4.Screw - 5.Oil - 6.Gas Path - 7.Timing Gears - 8.Bearings - 9.Shaft Seals - 10. Oil Seal



Lobe-type (Roots) Vacuum Pumps



- ❑ *Roots pumps have very high gas displacement speed. Sometime are called blowers.*
- ❑ *Roots pumps are generally considered as dry mechanical pumps, but their gear-box contain lubrication oil.*
- ❑ *Roots pump usually need a small backing pump.*




Roots Vacuum Pumps – Examples



Pumping speed



- Okta 250
(Dual-stage backing pump 65 m³/h)
- Okta 500
(Dual-stage backing pump 120 m³/h)
- Okta 1000
(Dual-stage backing pump 250 m³/h)
- Okta 2000
(Single-stage backing pump 630 m³/h)
- Okta 4000
(Backing pump 1.100 m³/h)
- Okta 6000
(Backing pump 1.100 m³/h)
- Okta 8000
(Backing pump 1.600 m³/h)





Pumping speeds measured in combination with backing pumps:
Okta 250 A – 1000 A in combination with two-stage backing pumps
Okta 2000 A – 8000 in combination with single-stage backing pumps



Claw Pumps – Principle




Claw Pumps – Typical Parameters



Turbomolecular Pumps (TMPs)




- ❖ *TMPs are axial compressors designed for pumping gases in the molecular flow regime. So a backing pump is required.*
- ❖ *The gas molecules are transported towards to fore-vacuum via momentum transfer from the rotating blades.*
- ❖ *Operation range: 10^{-2} to 10^{-11} torr*
- ❖ *Pumping speed: 10 to 10,000 l/s*
- ❖ *TMPs are throughput pumps, thus infinite pumping capacity*
- ❖ *Blade rotation speed ranges from 14,000 to 90,000 rpm - making them mechanically vulnerable*



Turbomolecular Pumps (TMPs) Cont.




- Axial compressor type pumps are very flexible designs:
 - # of stages
 - Various blade angles
 - Hybrid pumps
- Molecular flow exists through most of a TMP; however, transient and sometimes viscous flow occurs at the pump discharge.
- The key parameter of TMPs is compression ratio, which is gas mass dependent.
- Typical Compression ratios:
 - $N_2 - 10^8 \sim 10^{10}$
 - $He - 10^4 \sim 10^7$
 - $H_2 - 10^3 \sim 10^6$



TMP Pumping Mechanism (1)



- ❑ *Rotating pump blades accelerate gas molecules in a preferred direction.*
- ❑ *To achieve effective compression, the blade tip speed needs to be comparable to the mean velocity of the gas molecules*




Velocity distribution from moving blades






TMP Pumping Mechanism (2)



- ❖ Another way of looking at it, is to consider the rotors as moving “chevron baffles”. Their relative movement gives the baffles a higher conductance in one direction over the other.
- ❖ Steep rotor blade angles produce higher conductances, which produces higher pumping speeds.
- ❖ Shallow rotor blade angles produce higher compression ratios.



TMP Pumping Mechanism (3)




- The **stator** plays a complimentary role to the **rotor**.
 1. The stator slows down the gases and,
 2. Increases gas pressure without creating too much of a conductance limitation.
- The stator does its job in as short a distance as possible.
- Rotors and stators are considered as a "pair" making up a **"stage"**.



Gas flow through TMP blades:

$$F_1 W = F_1 a_{12} - F_2 a_{21}$$



$$\frac{F_2}{F_1} = \frac{a_{12}}{a_{21}} - \frac{W}{a_{21}}$$

where, $F_{1/2}$: molecular flux at inlet/outlet

a_{12} : gas transmission probabilities from inlet-to-outlet



a_{21} : gas transmission probabilities from outlet-to-inlet

W : Ho coefficient, the ratio of net flux to incident flux

At uniform temperature, $F_i = P_i$, the compression ratio K

$$K \equiv \frac{P_2}{P_1} = \frac{F_2}{F_1} = \frac{a_{12}}{a_{21}} - \frac{W}{a_{21}}$$

TMP Maximum Compression Ratio – I



Using Monte Carlo method, Kruger & Shapiro calculated K_{\max} as function of

- the blade angle (ϕ),
- the blade spacing-to-cord ratio (s/b),
- the normalized blade speed $s_r = v_b/v_p$, for single-stage (v_p is most-probable molecular speed).



TMP Maximum Compression Ratio – II



- ❖ "Flat" blades (small θ) yet higher compression ratio
- ❖ Compression ratio increases with blade speed exponentially up to molecular thermal speed, and levels off when $v_b \gg v_p$.


$$K_{\max} \propto \exp\left[\frac{v_b}{\sqrt{2kT/m}}\right] = \exp\left[\frac{v_b}{v_p}\right] \quad (s_r \leq 1.5)$$

- ❖ Outer edges of the blades contribute more with higher linear speed
- ❖ Compression ratio is also exponentially dependent on $m^{1/2}$.

Example: $s/b=1$, $v_b(\text{tip})=400 \text{ m/s}$, $\theta=30^\circ$

Gas Molecules	K_{\max}		
	Single Stage	Two-Stage	15-Stage
H ₂	1.6	~100	1000
Ar	4	~10 ⁶	~10 ⁹





- ❖ Experimentally measured compression ratios for a Pfeiffer TPU-400 pump
- ❖ In a blanked-off condition, gas is admitted to the foreline
- ❖ The measured compression ratio is the ratio of foreline pressure to inlet pressure

TMP Maximum Pumping Speed – I




Kruger & Shapiro: (When $K=1$)

$$W_{\max} = a_{12} - a_{21}$$

Chang & Jou [*JVST A19* (2001), p2900]:

$$W_{\max} = \frac{a_{12} - a_{21}}{1 - a_{21}}$$



TMP Maximum Pumping Speed – II




At $s_r \leq 1$ (or $v_b \leq v_p$):

$$W \propto \frac{v_b}{\sqrt{2kT/m}}$$

Since pumping speed $S = F_1 \times W$
and molecular arrival rate $F \propto (kT/m)^{1/2}$

$$S \propto v_b$$

Thus TMP pumping speed is independent of type of gases and inlet pressure (in molecular-flow region)



Measured Pumping Speed of Pfeiffer TPU-400 TMP




TMP Pumping Characteristics




- ❑ *Constant compression ratio (k) and pumping speed (S) for inlet pressure up to 10^{-5} torr.*
- ❑ *TMPs favor heavier gases. k has much stronger dependence on molecular mass, as compared to S .*

COMPRESSION RATIO vs FORELINE PRESSURE





PUMPING SPEED




Hybrid TMPs with Molecular Drag Stage



- ❑ Most modern TMPs are combined with a molecular drag stage to increase compression ratio.
- ❑ For the hybrid TMPs, backing pressure can be as high as ~ 1 torr.



TMPs – Drives and Bearings



TMPs – Types of Bearings



- ❑ *Typical turbine rotation speed range from 36,000 rpm for large TMPs, to 72,000 rpm for small TMPs. Such high speeds naturally raise questions as to a reliable bearing designs.*
- ❑ *There are three types of bearings from most TPM vendors*

- *Oil lubricated / steel ball bearings*

- + Good compatibility with particles by circulating oil lubricant
- Can only install vertically
- + Low maintenance

- *Grease lubricated / hybrid bearings*


- + Installation in any orientation
- + Suited for mobile systems
- + Lubricated for life (of the bearings)
- + Need cooling (forced air or water)


- *Free of lubricants / Magnetic suspension*

- + Installation in any orientation
- + Absolutely free of hydrocarbons
- + Low noise and vibration levels
- + No wear and no maintenance



A Typical Mechanical Pump Cart for CESR







- *Though capture pumps are preferred pumps for most accelerator vacuum systems, TMPs are suitable for long-term continuous operations for accelerator vacuum systems.*
- *Typical applications are for system with very high gas loads (such as ion beam sources), or specific gases (such as helium, hydrogen, etc. such as insolation vacuum of cryo-modules).*
- *Accelerator protection system is usually implemented to handle power failures, and for routine TMP maintenances. This include pneumatically actuated gate that can isolate the TMP from the accelerator vacuum system. Solenoid fore-line insolation valve should also included in the inter-lock.*





Example of a TMP Pumped Accelerator



ETA (Experimental Test Accelerator) II @ LLNL




Sometimes bad things happen to a TMP




Diffusion Pumps



- *A diffusion pump is a vapor jet pump, which transports gas by momentum transfer on collision with the vapor stream.*
- *Commonly used pump fluids are hydrocarbons and fluorocarbon.*
- *Vapor back-stream can be a source of contamination.*
- *However, with proper cold traps, the vapor back-stream can be minimized significantly, so it can be used for HV and even UHV systems.*
- *Diffusion pumps are extremely reliable, and require minimum maintenance. For example, for CESR's booster (the Synchrotron), we needed oil change every 30 years!*



Diffusion Pump Characteristics



Unlike TMPs, diffusion pumps favoring light gases

